sparklelights

INSTRUCTION MANUAL

SP0400.00

7ft Pre- Lit Frosted Alpine Fir

TOP TIPS BEFORE YOU START!

1. Please check that all parts are present before you start the assembly of your product, as once assembled, the product is exempt from our home approval policy.
2. For safety sake, check the lighting chains before assembly, for any product that has cut, damaged or frayed wire insulation or power cords, cracks in the lamps or enclosures, loose connections or exposed cooper wire, if in any doubt do not use.
3. Do not connect lighting set to the power mains while it is in packaging.
4. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
5. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble your product safely.
6. We recommend that, where possible, all items are assembled near to the flat area in which they will be placed in use, to avoid moving the product unnecessarily once assembled. Never allow any part of the set to come into contact with a source of heat or flame.
7. Do not hang ornaments or other objects from power cord of light chains.
8. Please keep plastic bags out of reach of children and animals.
9. Locate your tree on a level surface that will not be damaged by the tree or decorations that could detach.
10. During assembly please take care not to over-tighten any fittings, as this may damage the product.

CARE AND MAINTENANCE OF YOUR PRODUCT

- Retain instruction manual for future use.
- This set of lights is fitted with led bulbs, it is important to follow these instructions to ensure the satisfactory and safe operation of these lights in use. This set has been designed so that under normal conditions, if a bulb fails the remaining bulbs should stay alight.
  A defective bulb can not be removed and replaced.
- This set can be operated in INDOOR USE ONLY.
- Disconnect from power mains whenever not in use.
- Avoid damage to the transformer and wiring insulation.
- As with all electrical equipment, cable and fittings should not be exposed to fire, candles or any other direct sources of heat and any damp wet and humid areas.
- Do not connect this set to any other power source.
- Do not connect this set electrically to another light chain.
- Do not connect this set directly to a mains supply without the low voltage transformer.
- Do not close doors or windows on the product power cords as this may damage the wire insulation.
- Do not cover the power supply with cloth, paper or any material not part of the product when in use.
- If the supply cord becomes damaged the item must be discarded.
- Do not use if there is any damage to the light insulation, please check electrical part and all fittings periodically.
- When you have finished using, repack step by step carefully to avoid damage to ensure that your tree can be used again.
- Make sure the storage area is dry; avoid any damp, wet and humid areas.

THIS IS A CHRISTMAS DECORATION IT IS NOT A TOY AND NOT INTENDED FOR USE BY CHILDREN AND PETS.

Transformers:
This set is supplied with 31V AC 6W transformer and should only be used with this transformer.

IMPORTANT


MPORTANT: PRODUCT CAN BE USED IN COMPLETE SAFETY INDOOR ONLY, PLEASE ENSURE THAT THE TRANSFORMER IS NOT PLACED IN DAMP AREAS.

SPECIFICATION

CAT NO. SP0400.00

LEAD WIRE LENGTH	5M
LED BULB RATING	Max.3.0V 20mA *400
TRANSFORMER INPUT	220-240V~50-60Hz
TRANSFORMER OUTPUT	31V AC 6W
MAXIMUM RATINGS	31V 6W

ASSEMBLED DIMENSIONS



NO.	PART LIST	QTY
(1)	Top section of tree	1
(2)	Middle section of tree	1
(3)	Bottom section of tree	1
(4)	Stand	1
(5)	Transformer	1
(6)	Bolt	3

ASSEMBLY INSTRUCTIONS

1. Loosen the bolt and slide the feet on the stand apart (see Fig.1)
2. Insert the bottom section of the tree into the stand first, then tighten bolt. Insert the final 2 sections (see Fig. 2)
3. Connect 2 parts of light chain.
4. To shape your tree, pull down the tree tips and shift branches to fill any gaps.
5. Finally, connect the power source (see Fig 3). Your tree is ready to enjoy.

Fig. 1




Fig. 2





Fig. 3



INSTRUCTIONS FOR MULTI-FUNCTION CONTROLLER

Press the button on the enclosure of the controller to control the operating mode of the light set. The controller allows the light set to be used in 8 different operating modes as follows:

1. Combination of modes 2 to 7;
2. In waves
3. Sequential
4. SLO GLO
5. Chasing / Flash
6. Slow fade
7. Twinkle / Flash
8. Steady on.

Timer Function: Press the button twice to activate the timer. (6 Hours on/18 Hours off)
Note: Disconnecting the power will reset the timer. The timer must be reactivated when the product is powered on again.

WEEE RECYCLE

This symbol indicates that this product is classed as Electrical or Electronic Equipment and should not be disposed of with other household waste. The Waste Electrical and Electronic Equipment (WEEE) Directive has been introduced across the European Union to recycle waste electrical products using the best available recovery and recycling techniques in order to minimize the impact on the environment, to treat any hazardous substances, and to avoid increasing landfill.
WEEE products should be disposed of by handing them over at a designated collection point. For more information about where you can drop off your waste product for recycling, please contact your local authority.

CE UKCA III RoHS

Imported by Sparklelights Lighting Ltd
14 Pippin Road, Malton, North Yorkshire, YO17 7YT, U.K.
Any queries or comments please email Team@sparklelights.com

BATCH CODE: 0926 MADE IN CHINA